

DataMaster DMT Equipment Readiness checklist for Repaired Equipment.

- Check that there is a TSI started and printed for this instrument.
- Check that the correct version of software hardware is on this instrument
- Fill the instruments assigned simulator with fresh Stock solution ~0.1 ETOH
- Use the Calibration Protocol, and Procedure to calibrate the instrument
- Use the assigned simulator (from above after at least ½ an hour has passed to run an accuracy and precession check this is also a calibration check.
- Print a second copy of the A+P
- Use the certification protocol and procdure to certify the instrument.
- Complete the TSI
- Submit the paperwork for peer review