

DataMaster DMT Equipment Readiness checklist for NEW Equipment

- Receive instruments from shipping and receiving
- Sign packing slip, copy and send downtown
- Remove the instrument from the box, and place on counter or shelving
- Perform power up testing
- Perform linearity testing
- Perform interference testing
- Check that Volume reading is accurate
- Assign a simulator to the instrument, modify the simulator if needed
- The instrument is now accepted for use.
- Prepare the Instrument for field use; attach the keyboard, stylus, identification sticker and security screws.
- From this checklist move to the DataMaster DMT Equipment Readiness checklist for Repaired Equipment.